

SAFETY INSTRUCTIONS

masunt Flush-mounted frames (all models)

Installation should only be carried out by qualified personnel.

Before installation, ensure that the surface is suitable for the installation (e.g. load-bearing masonry or concrete walls).

Ensure that there are no electrical cables, water or gas pipes running through the wall before drilling holes.

Only use suitable fastening material according to the wall condition.

The flush-mounted frame must be flush with the wall to ensure secure installation of the key safe.

After installation, check that the key safe is securely seated in the flush-mounted frame.

