

SAFETY INSTRUCTIONS

DIGITAL LOCKS Digital locks (all models)

Installation should be carried out in accordance with the instructions supplied and by qualified personnel.

These digital locks are designed for the electronic locking of cabinets, lockers, safes and similar containers.

During installation, ensure that all components are correctly aligned and firmly connected.

Before fixing, check whether the door or flap is suitable for installing the lock.

Access codes, RFID cards or electronic keys should not be passed on to unauthorised persons.

Standard access codes should be changed immediately after installation.

The lock must not be opened or mechanically modified without authorisation, as this may impair its functionality and security.

The manufacturer accepts no liability for damage caused by improper use, incorrect installation or tampering.







Resatur GmbH | masunt | Klopstockstraße 5 | 22765 Hamburg www.masunt.com | info@masunt.com | +49 (0)40 716 629 905