

SAFETY INSTRUCTIONS RFID Smart Cards (all models)

Keep the smart cards safe and protect them from unauthorized access.

Avoid bending, breaking or mechanically damaging the cards.

RFID smart cards should not be exposed to excessive pressure, heat or moisture.

Hold the card close to the RFID reader when scanning and avoid unnecessary movements during the scanning process.

The card must not be drilled, cut or otherwise modified, as this may impair its functionality.

If the card is lost or stolen, it should be removed from the system or blocked immediately.

Store the cards in a dry and cool place, away from direct sunlight or extreme temperatures.

The cards contain RFID technology that can be read wirelessly. Protect the cards against unauthorized access using suitable protective measures (e.g. RFID protective sleeves).

The manufacturer accepts no liability for damage caused by improper use, modification or misuse of the RFID smart cards.

Use a soft, dry cloth to clean the cards - do not use aggressive cleaning agents or solvents.



Resatur GmbH | masunt | Klopstockstraße 5 | 22765 Hamburg www.masunt.com | info@masunt.com | +49 (0)40 716 629 905